

COIL WIDTH (in)

COIL HEIGHT (in)

	22-23	24-31	32-39	40-47	48-55	56-61	62-71	72-81	82-97	98-107	108-119	120-144
22-23	1x 18" lamp	1x 18" lamp	2x 18" lamp	2x 18" lamp	2x 18" lamp	2x 18" lamp	2x 18" lamp	2x 18" lamp	3x 18" lamp	3x 18" lamp	3x 18" lamp	4x 18" lamp
24-31	1x 18" lamp	2x 18" lamp	2x 18" lamp	2x 18" lamp	2x 18" lamp	2x 18" lamp	3x 18" lamp	3x 18" lamp	3x 18" lamp	3x 18" lamp	4x 18" lamp	4x 18" lamp
32-39	2x 18" lamp	2x 18" lamp	2x 24" lamp	2x 24" lamp	2x 24" lamp	2x 24" lamp	3x 24" lamp	3x 24" lamp	3x 24" lamp	3x 24" lamp	4x 24" lamp	4x 24" lamp
40-47	2x 18" lamp	2x 18" lamp	2x 24" lamp	2x 36" lamp	2x 36" lamp	2x 36" lamp	2x 36" lamp	2x 36" lamp	3x 36" lamp	3x 36" lamp	3x 36" lamp	3x 36" lamp
48-55	2x 18" lamp	2x 18" lamp	2x 24" lamp	2x 36" lamp	2x 36" lamp	2x 48" lamp	3x 36" lamp	3x 36" lamp	3x 36" lamp	3x 36" lamp	3x 36" lamp	4x 36" lamp
56-61	2x 18" lamp	2x 18" lamp	2x 24" lamp	2x 36" lamp	2x 48" lamp	2x 48" lamp	2x 48" lamp	2x 48" lamp	2x 48" lamp	3x 48" lamp	3x 48" lamp	3x 48" lamp
62-71	2x 18" lamp	3x 18" lamp	3x 24" lamp	2x 36" lamp	3x 36" lamp	2x 48" lamp	3x 48" lamp	3x 48" lamp	3x 48" lamp	3x 48" lamp	4x 48" lamp	4x 48" lamp
72-81	2x 18" lamp	3x 18" lamp	3x 24" lamp	2x 36" lamp	3x 36" lamp	2x 48" lamp	3x 48" lamp	2x 64" lamp	3x 64" lamp	3x 64" lamp	3x 64" lamp	3x 64" lamp
82-97	3x 18" lamp	3x 18" lamp	3x 24" lamp	3x 36" lamp	3x 36" lamp	2x 48" lamp	3x 48" lamp	3x 64" lamp	4x 36" lamp	4x 48" lamp	4x 48" lamp	4x 64" lamp
98-107	3x 18" lamp	3x 18" lamp	3x 24" lamp	3x 36" lamp	3x 36" lamp	3x 48" lamp	3x 48" lamp	3x 64" lamp	4x 48" lamp	4x 48" lamp	4x 48" lamp	4x 64" lamp
108-119	3x 18" lamp	4x 18" lamp	4x 24" lamp	3x 36" lamp	3x 36" lamp	3x 48" lamp	4x 48" lamp	3x 64" lamp	4x 48" lamp	4x 48" lamp	6x 36" lamp	6x 48" lamp
120-144	4x 18" lamp	4x 18" lamp	4x 24" lamp	3x 36" lamp	4x 36" lamp	4x 48" lamp	4x 48" lamp	3x 64" lamp	4x 64" lamp	4x 64" lamp	6x 48" lamp	6x 64" lamp

KEY:

Horizontal Orientation	Vertical Orientation	Horizontal or Vertical
------------------------	----------------------	------------------------

Rules:

- Max 36 inches between parallel (stacked) lamps.
- Max 12 inches between end to end lamps.
- Max 6 inches from the end of the lamp to the edge of the coil.

- Install lamps 6-18 inches from the coil surface: 12 inches is optimal.
- No overlapping lamps.
- Lamp must fit in range indicated, if not select smaller lamp.
- 300 microwatts/cm² target.

